

August International Ltd
United Kingdom
Telephone: +44 (0) 845 250 0586
www.augustint.com

August[®] User Manual

—— CR225 ——

- EN Bluetooth FM Transmitter
- FR Transmetteur FM Bluetooth
- DE Bluetooth FM Transmitter
- IT Trasmettitore FM Bluetooth
- ES Transmisor FM Bluetooth

User Manual

Thank you for purchasing the August Bluetooth FM Transmitter. This user manual is designed to familiarize you with all the features of this device. Please take time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device.

Please do not disassemble the CR225, it can be unsafe and will invalidate the manufacturer's warranty.

Disposal

Please ensure the product and accessories are disposed in compliance with WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations in your country.







Always check with the environment agency and any other relevant authorities for current disposal regulations.

Customer Service

You can contact us by phone on: +44 (0) 845 250 0586 or by email at: service@augustint.com should you require further technical support or customer service.

1. Safety Instructions

■ Storage and Use

	Keep this device away from extreme temperatures.		Keep the device away from wet or damp environment.
	Never expose the device to moisture, dust, oil or smoke.		Avoid dropping or exposing to impacts.
	When carrying this device as part of your luggage please ensure it is securely stored to avoid impact damage.		Never strike or scratch this device with any sharp object.

■ Maintenance

Please unplug all leads before cleaning this device.

	Wipe the device and buttons with a soft cloth.		Never wipe this device with an abrasive cloth or apply detergent, alcohol or chemical based cleaning products.
---	--	---	--

2. Main Features


- Wirelessly connect your mobile phone to your car stereo.
- Take calls hands free through the integrated microphone.
- Powered USB socket for charging your portable electronics.
- Powered by internal battery or 12V~24V cigarette lighter socket.

3. Accessories



- 1) User manual

4. Device Layout



1. Power button
2. Volume dial
3. Status LED
4. Screen
5. Microphone
6. Previous
7. Next
8. FM frequency dial
9. USB output

5. Operating

5.1 Power

Press and hold the power button to turn the device off or on.

Note: The CR225 will automatically turn on when connected to a 12V~24V power socket and automatically turn off after 10 minutes if it is not connected to a Bluetooth source.

5.2 Bluetooth Connections

When turned on, the CR225 enters pairing mode automatically indicated by the status LED flashing blue.

Scan for Bluetooth devices on your mobile phone and select CR225 from the available devices.

After successful connection, the status LED will light blue.

The CR225 will attempt to reconnect to the last paired device when it is turned on. To connect to a new device, first disconnect any existing connection.

Note: Bluetooth settings on mobile phones are not standardised, to find the specific information for your phone, please refer to its user manual.

5.3 FM Transmission

The LCD screen displays the current FM transmission frequency. Match your FM radio to this frequency to begin playback through your car stereo. To reduce interference, find an empty station on your FM radio then use the FM frequency dial to match this number on the CR225.

5.4 Music Control

The CR225 can control the music playing on a compatible Bluetooth device.

Use the volume dial to adjust the volume.

Press ◀◀ or ▶▶ to skip to the next or previous track.

Press the power button to play, pause and resume playback.

5.5 Hands-free Calling

Whilst connected to your mobile phone, the CR225 will act as a hands-free system for phone calls.

Press the power button on the CR225 to pick up or hang up calls. Press and hold the power button for 2 seconds to reject the incoming call.

Double press the power button to redial the last called number.

5.6 USB Output

Whilst the CR225 is connected to a 12V~24V power source, the USB port on the CR225 acts as a powered USB port to charge portable devices.

6. Specifications

Bluetooth version	VER2.1+EDR
Bluetooth profile	HFP/HSP, OPP, A2DP/AVRCP, PBAP
Frequency response	20Hz~16KHz
Working distance (Bluetooth)	About 10m
FM frequency	88.1~107.9MHz
Working distance (FM)	About 5m
Power input	DC 12V ~ 24V
USB output voltage	DC 5V 1A
Internal Battery	200mAh
Charging time	1 hour
Working time	2.5 hours
Dimensions	110×65.5×40mm
Net weight	191g

7. Troubleshooting

■ The device will not turn on.

- 1) Check that the CR225 is securely plugged into the 12V~24V power source.
- 2) Check that the 12V~24V power source is working.

■ No sound is heard.

- 1) Check that the volume level on your Bluetooth device, CR225 and FM radio is not too low.
- 2) Check that the FM frequency of the CR225 and the FM radio match.

■ The sound quality is intermittent.

- 1) Check that the FM frequency of the CR225 and the FM radio match.
- 2) Check that the FM frequency is clear of FM radio broadcasting.

■ The microphone volume is too low.

- 1) Turn the microphone on the CR225 to face you.
- 2) Move the CR225 closer to you.

8. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main unit, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexperienced repairs. The manufacturer disclaims any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.
- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586

Email: service@augustint.com